


HI-3P(5-12)k-H Series Quick Guide

Ver 1.0 202308


1. Overviews

Appearance:




No.	Parts	No.	Parts
1	DC switch	6	AC terminals
2	PV input terminals	7	Generator
3	Battery terminals	8	LED display
4	Communication module port	9	Protective grounding terminal
5	Communication port	10	Wall mounts

System Overview:




1

2. Installation environment requirements



3. Install inverter




4. Connecting Cables


No.	Cable	Type	Outer Diameter	Cross Section	
1	PV cable	Outdoor multi-core copper wire cable(Such as PV1-F)	6~9 mm	4~6 mm ²	
2	Battery cable	Complying with 1,000V and 30A standard Battery has its own power cable and communication cable ,use them directly .	6~9 mm	4~6 mm ²	
3	Communication cable	Shielded twisted pair	4.5~6 mm	2*(0.5~1.0) mm ²	
		CAT 5E	4.5~6 mm	8*0.2 mm ²	
4	AC cable	Grid	Outdoor multi-core copper wire cable	13~18 mm	4~6 mm ²
		Backup		14~17.5 mm	4~6 mm ²
		Diesel generator			
5	Grounding cable	Outdoor single-core copper wire cable	The same as that of the PE wire in the AC cable		

2

5. Grounding Connection




6. PV Connection




3

7. Battery Connection




If Lithium Battery has its own power cable and communication cable ,please use them directly .

8. AC Connection




4

9. Generator Connection(Optional)



9.1 Communication port definition




5


No.	Pin definition	Function	No.	Pin definition	Function	
1	DO1+	Dry contact	13	CAN_L	CAN	
2	DO1-		14	CAN_L		
3	DO2+		15	CAN_H		
4	DO2-		16	CAN_H		
5	FB_CTR_B	Dry contact	17	RS485_A	RS485	
6	FB_CTR_A		18	RS485_A		
7	DRM1/5	DRED	19	RS485_B		RS485
8	DRM2/6		20	RS485_B		
9	DRM3/7		METER	RS485		
10	DRM4/8		BMS	CAN		
11	DRM0					
12	REF/GEN					

9.2 Other devices connection (Optional)


■ Connect the DRM connection



■ Connect other cables





9.3 Communication port installation



6

9.4 Smart meter and CT connection

■ RJ45 terminals definition (to inverter)




PIN	Color	Pin definition
1	Orange White	NC
2	Orange	
3	Green White	RS485_A
4	Blue	
5	Blue White	RS485_B
6	Green	NC
7	Brown White	
8	Brown	


9.5 BMS port connection

■ RJ45 terminals definition (to inverter)

PIN	Color	Pin definition
1	Orange White	TEMP+
2	Orange	NC
3	Green White	TEMP-
4	Blue	CAN_H
5	Blue White	CAN_L
6	Green	NC
7	Brown White	RS485_A
8	Brown	RS485_B



10. Communication Module Connection (Optional)



7

11. Checking Before Operation

No.	Check Items
1	The inverter installed firmly that easily for operation and maintenance.
2	All lines, including PE, PV, Battery, AC and communication, are connected correctly and firmly.
3	The cable bundling complies with the wiring requirements, is properly distributed, and free from damage.
4	Ensure that a waterproof cover is installed for unused wire holes
5	Ensure that the used wire holes have been sealed
6	Verify that the voltage and frequency of installed location meet the grid-tied requirement

12. System Power On/Off

Before turning on the AC switch between the inverter and the grid, use a multimeter to check that the AC voltage is within the allowed range.

Step 1: Turn on the AC circuit breaker on the ON-GRID side of the inverter.

Step 2: Turn on the AC circuit breaker on the BACK-UP side of the inverter.

Step 3: Turn on the energy storage circuit breaker between the inverter and the battery.

Step 4: Turn on the DC switch of the inverter.

Step 5: Send a system check command on the APP (optional).

Step 6: Observe the LEDs to check the inverter operating status.

To shutdown steps are opposite to the above order.

LED	Status	Description			
Fault	Red LED indicator on	A fault has occurred	COM	LED indicator on	BMS and meter communication are ok
	Red LED indicator on blink 1	RCM OR IRD fault		LED indicator blink1/blink2	BMS or meter communication fails
	Off	No fault		LED indicator off	Both BMS and meter communications are fails
PV	LED indicator on/blink1	PV is generating power	SOC	Full LED indicators on	Each indicator means Battery SOC is 25%
	LED indicator off	PV is not working		One LED indicator blink1	Battery SOC is below 10%
AC	LED indicator on	Grid is active and connected		Full LED indicators off	Battery is disconnected / not active
	LED indicator blink1	Grid is disconnected but EPS is on			
	LED indicator off	Grid is disconnected and EPS is off			

13. Service and contact

Web:www.yienergy.com/en/service/

E-mail:support@yienergy.com

Tel:+86-400-103-7723

Address:No.161 Yuancheng Road, Qiantang District, Hangzhou, Zhejiang, China

YI Energy Technology (Zhejiang) Co., Ltd.

8